

Thank You for Purchasing a



**TRIDENT™**

SINGLE ZONE CONTROLLER

**Model T3A**

**Automatic Misting Controller**

## **INSTRUCTION MANUAL**

*Please read entire Instruction Manual  
(including Limited Warranty)  
before installation.*



13688 Rider Trail North

Earth City, MO 63045

(314) 770-0717 • Fax: (314) 506-4587



- 1) "ON" Time Rotary Switch
- 2) "OFF" Time (or Time Between Cycles) Rotary Switch
- 3) MODE Selector Switch
- 4) Seconds/Minutes ("A" Mode) LED
- 5) Minutes/Minutes ("B" Mode) LED
- 6) Minutes/Hours ("C" Mode) LED
- 7) Solenoid "ON" LED
- 8) Solenoid "OFF" LED
- 9) Event (or Program) 7- Segment Display
- 10) Clock/Timer 7- Segment Display
- 11) "DOWN" Button
- 12) "UP" Button
- 13) "ENTER" Button
- 14) Power Plug (24 Volts AC)
- 15) Solenoid Plug